



ALL PERIMETER NAILERS, NEW OR EXISTING SHALL BE FASTENED IN ACCORDANCE WITH THE FOLLOWING SCHEDULE (UNLESS NOTED OTHERWISE ON DETAIL DRAWINGS)

ATTACHMENT SUBSTRATE	PERIMETER FASTENER SPACING (MAXIMUM)	CORNER FASTENER SPACING (MAXIMUM)
STRUCTURAL CONCRETE	12" O.C.	6" O.C.
CMU (FASTENER INTO SOLID MATERIAL)	12" O.C.	6" O.C.
STEEL DECK	12" O.C.	6" O.C.
WOOD	12" O.C.	6" O.C.

NOTES:

1. FASTENERS IN 6" OR WIDER (NOMINAL) LUMBER SHALL BE INSTALLED IN TWO (2) ROWS, STAGGERED 1/3 OF NAILER WIDTH.
2. TWO (2) FASTENERS SHALL BE INSTALLED WITHIN 6" OF EACH NAILER END.
3. CORNER FASTENER SPACING SHALL EXTEND 8' FROM ALL OUTSIDE BUILDING CORNERS.
4. WHERE TWO OR MORE NAILERS ARE INSTALLED, EACH NAILER SHALL BE FASTENED INDEPENDENTLY.
5. OVER ALL DECK TYPES, THE BOTTOM NAILER SHALL BE FASTENED USING THE SPECIFIED FASTENERS AND 5/8" DIAMETER WASHERS. COUNTERSINK WASHERS AND FASTENERS LEVEL WITH TOP OF WOOD USING SPADE BIT OR SIMILAR METHOD. FASTEN SUBSEQUENT NAILERS, WHERE SPECIFIED, USING THE SPECIFIED SCREWS WITHOUT WASHERS.
6. FASTENER TYPES ARE DETERMINED BY SUBSTRATE MATERIALS AND SECTION 06100 ROUGH CARPENTRY.
7. NAILERS SHALL BE INSTALLED WITH 1/4" GAP BETWEEN ENDS OF ADJOINING PIECES.
8. REFER TO SECTION 06100 FOR ADDITIONAL REQUIREMENTS.

NAILER ATTACHMENT GUIDELINES AT PERIMETER